

Start of Day :

1

Turn your PoliCool upside down and shake vigorously for a **minimum of 30 seconds** or until mixed completely. Repeat every hour of use.

2

Insert tube and filter. Load PoliCool into your Dual Disc II making sure to align under drain

3

Power ON Dual Disc II (Back of Machine)

4

Press the **1** Use the **2** to scroll to the **Pump Prime** screen. Pressing the **3** button turns on the PoliCool pump for 60 seconds. Press the **1** to exit.

5

Verify liquid is coming out of both spouts with no air bubbles to ensure liquid is flowing well

6

Snap 2 discs into place, close and latch lid and your ready to start your first cycle

End of Day :

1

Remove PoliCool cartridge from machine, place lid back on the bottle.

2

Wipe down the surfaces and "Quick Load Assemblies" after each shift to prevent PoliCool build up. Use Spray Cleaner and a soft cloth.

3

Power OFF your Dual Disc II. (Back of Machine)



IMPORTANT!

DO NOT DISCARD

Reference Guide.

Mount Near Machine

For Daily Viewing.

Azuradisc Inc.

7307 South 89th Place

Mesa, AZ 85212

Toll Free 1-800-933-4923

WWW.AZURADISC.COM